(b) Resistant to deterioration by the product for which the portable tank is approved.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990]

§98.30-9 Stowage of portable tanks.

- (a) No person may operate a vessel to which this subpart applies unless each portable tank is stowed on an open deck.
- (b) No person may stow a portable tank—
- (1) In the vicinity of another tank that contains a chemically incompatible product; and
- (2) Unless all electrical equipment is explosion-proof or intrinsically safe, as defined in §§111.105–9 and 111.105–11 of this chapter, in the area of the tank and its associated equipment that is—
- (i) Within 10 feet in any horizontal direction; and
 - (ii) Within 8 feet above the deck.

[CGD 73–172, 39 FR 22954, June 25, 1974, as amended by CGD 84–043, 55 FR 37412, Sept. 11, 1990; 55 FR 47477, Nov. 14, 1990]

§98.30-10 Pipe connections, and filling and discharge openings.

No person may transfer a hazardous material to or from a portable tank on board a vessel, unless each filling and discharge opening in the tank bottom is equipped with the following:

- (a) For an IM 101 or IM 102 portable tank, the closures specified in 49 CFR 173.32c(g)(2); and
- (b) For an MPT, the valves and closures specified in §§ 64.33 through 64.41 of this chapter.

[CGD 84-043, 55 FR 37412, Sept. 11, 1990]

§98.30-11 Cargo pumps.

No person may operate a cargo pump to transfer a product to or from a portable tank unless the pump is installed—

- (a) Above deck; or
- (b) Below deck, in conformance with subpart 32.60 of this chapter.

§ 98.30-13 Ground connection.

No person may transfer an inflammable or combustible product to or from a vessel unless—

(a) The portable tank and its pumping equipment is electrically grounded to the hull of the vessel; and

- (b) The vessel is electrically grounded to an offshore platform, shore piping, or another vessel by a—
- (1) Cargo hose constructed with an integral grounding wire if the end connections are used for electrical continuity: or
- (2) Separate grounding that is maintained until the cargo hose is disconnected and drained.

§98.30-14 Requirements for ships carrying NLSs in portable tanks.

- (a) The person in charge of a ship, except a ship under subpart 98.31 of this chapter, that carries an NLS in a portable tank shall ensure that—
- (1) The ship's Certificate of Inspection is endorsed with the name of the NLS:
- (2) Any letters issued by the Commandant (G-MSO) prescribing additional conditions for endorsement are attached; and
- (3) Each operating requirement specified in writing by Commandant (G-MSO) as a condition for endorsement is met.
- (b) To have a ship's Certificate of Inspection endorsed to allow the carriage of NLSs in portable tanks, the—
- (1) Owner of the ship must make a request to the Commandant (G-MSO) following the procedures for requesting alternatives in §153.10(a) of this chapter; and
- (2) The ship must meet any design and equipment requirements specified in writing as a condition for the endorsement by the Commandant (G-MSO).

[CGD 81-101, 53 FR 28974, Aug. 1, 1988. Redesignated at CGD 84-043, 55 FR 37411, Sept. 11, 1990, and amended by CGD 84-043, 55 FR 37412, Sept. 11, 1990; CGD 95-072, 60 FR 50464, Sept. 29, 1995; CGD 96-041, 61 FR 50730, Sept. 27, 1996]

§ 98.30-15 Leakage containment.

(a) No person may transfer a product to or from a vessel unless there is a container or enclosed deck area that meets the requirements of this section under or around each transfer connection area.